


Earthquake[®]

E43 Power Earth Auger



Operator's Manual

IBE43
8/16/05

© Copyright 2005 Ardisam, Inc.
All Rights Reserved. Printed in USA.

THANK YOU . . .

for purchasing an Earthquake® Power Earth Auger from Ardisam, Inc. We have worked to ensure that it meets high standards for usability and durability. With proper care, your auger will provide many years of service. Please take the time to read this manual carefully to learn how to correctly operate and maintain your auger. Congratulations on your investment in quality.

REGISTRATION

Fill out and mail the registration card located in your parts packet. Warranty is valid only if your completed registration card is received by Ardisam, Inc., at time of purchase.

Model Number _____

Serial Number _____

Engine Serial Number _____

Date of Purchase _____

Place of Purchase _____

WARRANTY**One Year Limited Warranty**

The Ardisam, Inc., Manufacturing Company warrants this Earthquake® Earth Auger to be free from defects in material or workmanship. Conditions of this warranty include:

What is covered under warranty:

For the first year from the date of purchase, Ardisam will furnish 100% parts and labor to correct any defect caused by faulty material or workmanship. All repairs made under warranty must have prior approval from Ardisam, Inc. Items subject to normal wear and tear, due to the nature of their function are not covered under this warranty. Any unit used in a commercial application is covered for a period of 90 days after purchase.

What is not covered under warranty:

This warranty applies only to products which have not been repaired or altered outside our factory. It covers only defects resulting from normal use, and does not cover defects arising from misuse, alteration, negligence, or accident. This warranty applies only to the original purchaser, and is not transferrable.

How to obtain service:

Call 1-800-345-6007 for service assistance, or return the product to us at the address below with transportation charges prepaid.

This warranty supersedes all other warranties either expressed or implied and all other obligations or liabilities on our part. Ardisam, Inc., does not assume, and does not authorize any other person to assume for us, any liability in connection with the sale of our products. This guarantee is void unless the warranty card is properly filled out and returned to Ardisam, Inc., Cumberland, Wisconsin, within two weeks of the purchase date.



Ardisam, Inc.
1690 Elm Street, Cumberland, WI 54829
Phone (715) 822-2415 Fax (715) 822-2223
1-800-345-6007
Email info@ardisam.com
www.ardisam.com

Owner's Responsibility

Accurate assembly and safe and effective use of the auger is the owner's responsibility.

- Read and follow all safety instructions.
- Carefully follow all assembly instructions.
- Maintain the auger according to directions and schedule included in this earthquake operator's manual.
- Ensure that anyone who uses the auger is familiar with all controls and safety precautions.

Special Messages

Your manual contains special messages to bring attention to potential safety concerns, machine damage as well as helpful operating and servicing information. Please read all the information carefully to avoid injury and machine damage.



CAUTION

Avoid injury! This symbol and text highlight potential hazards or death to the operator or bystanders that may occur if the hazards or procedures are ignored.



Avoid damage! This text is used to tell the operator of actions or conditions that might result in damage to the machine.

NOTE: General information is given throughout the manual that may help the operator in the operation or service of the machine.



WARNING

CALIFORNIA PROPOSITION 65 WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Important Safety Precautions

Please read this section carefully. Operate the auger according to the safety instructions and recommendations outlined here and inserted throughout the text. Anyone who uses this auger must read the instructions and be familiar with the controls.



This symbol points out important safety instructions which if not followed could endanger your personal safety. Read and follow all instructions in this manual before attempting to operate this equipment.

- Do not carry the auger powerhead between holes with the engine running.
- The auger should not rotate when the engine is idling. If it does rotate when engine is idling, contact Ardisam, Inc. at 1-800-345-6007 for instructions.
- Always keep hands, feet, hair and loose clothing away from any moving parts on engine and auger.
- Do not allow children to operate this power auger. Do not allow adults to operate the auger without proper instruction.
- Do not operate any power equipment under the influence of alcohol or drugs.
- Keep all screws, nuts and bolts tight.
- Engine should be turned off and cool, spark plug wire must be removed from spark plug before any repairs are attempted.
- Temperature of muffler and nearby areas may exceed 150° F (65° C). Avoid these areas.
- Never run engine indoors or in an enclosed area. Engine exhaust contains carbon monoxide, an odorless and deadly gas.
- If the earth auger becomes unturnable in a hole, turn engine off and allow to cool before attempting to remove it manually.
- Use only original equipment parts from Ardisam, Inc. including all nuts and bolts.

Engine Safety Precautions

Warning Carbon Monoxide Poisoning

All engines contain carbon monoxide in their exhaust. Carbon monoxide is a deadly, colorless, tasteless, odorless gas which may be present even if you do not smell or see any engine exhaust. Levels of carbon monoxide, which can be deadly, can be present for days in an enclosed area that has poor ventilation. Any level of carbon monoxide, if inhaled, can cause headaches, drowsiness, nausea, dizziness, confusion and eventually death. If you experience any of these symptoms, seek fresh air and **medical attention immediately**.

Preventing Carbon Monoxide Poisoning

- Never run engine indoors.
- Never try to ventilate engine exhaust indoors. Carbon monoxide can reach dangerous levels very quickly.
- Never run engine outdoors where exhaust fumes may be pulled into a building.
- Never run engine outdoors in a poorly ventilated area where the exhaust fumes may be trapped and not easily taken away. (Examples include: in a large hole or areas where hills surround your working area.)
- Never run engine in an enclosed or partially enclosed area. (Examples include: buildings that are enclosed on one or more sides, under tents, car ports or basements.)
- Always run the engine with the exhaust and muffler pointed in the direction away from the operator.
- Never point the exhaust muffler towards anyone. People should always be many feet away from the operation of the engine and its attachments.

Gasoline Fires and Handling Fuel Safely

Fuel and fuel vapors are highly flammable. Never use fuel where a spark or flame may be present. Never use fuel where a potential source of ignition could occur. (Examples include: hotwater or space heaters, clothes dryer, electric motors, etc.) Keep flames and sparks away from engine and fuel to prevent fires. Fuel fires spread very quickly and are highly explosive.

Prevention of Gasoline Fires

- Never fill your fuel tank with fuel indoors. (Examples include: basement, garage, barn, shed, house, porch, etc.)
- Always fill fuel tank outside in a well ventilated area.
- Never remove the fuel cap or add fuel with the engine running. Stop engine and allow to cool before filling.
- Never drain fuel from engine in an enclosed area.
- Always wipe up excess (spilled) fuel from engine before starting. Clean up spilled fuel immediately.
- Allow spilled fuel to dry, after wiping and before starting.
- Allow fuel fumes/vapors to escape from the area before starting engine.
- Test the fuel cap for proper installation before starting and using engine.
- Always run the engine with fuel cap properly installed on the engine.
- Always unscrew gas cap vent screw while engine is running.
- Never smoke while refilling engine fuel tank.
- Prevent fire and explosion caused by static electric discharge. Use only non-metal, portable fuel containers approved by the Underwriter's Laboratory (U.L.) or the American Society for Testing & Materials (ASTM).
- Do not store engine with fuel in fuel tank indoors. Fuel and fuel vapors are highly explosive.
- During storage, screw down gas cap vent screw tightly.
- Never pour fuel from engine fuel tank.
- Never siphon fuel by mouth to drain fuel tank.
- Always have an adult fill the fuel tank.
- Never allow anyone under the influence of drugs or alcohol to fill engine.
- Never allow children to fill the engine.
- The clutch will transfer maximum power after about two hours of normal operation. During this break-in period clutch slippage may occur. The clutch should be kept free of oil or other moisture for efficient operation.

Burns and Fires

The muffler, muffler guard and other parts of the engine become extremely hot during the operation of the engine. These parts remain extremely hot after the engine has stopped.

Prevention of Burns and Fires

- Never remove the muffler guard from the engine.
- Never touch the muffler guard because it is extremely hot and will cause severe burns.
- Never touch parts of the engine that become hot after operation.
- Always keep materials and debris away from muffler guard and other hot parts of the engine to avoid fires.

This engine is designed to operate using a catalytic converter which contributes to the engine's compliance with the EPA.

CAUTION

Avoid injury! Hot gases are a normal by-product of a functioning catalytic converter. Follow all safety instructions to prevent burns and fires.

Steps for Working on Engine or Attachment

CAUTION

DO NOT Alter/Modify Engine or Attachments: Avoid injury! Never alter or modify the engine from the factory. Serious injury or death may occur if engine is modified or altered.

CAUTION

Avoid injury! When working on or replacing parts for the engine or attachments you must always disconnect spark plug wire from the spark plug and keep it away from the spark plug.

1. Turn off engine switch.
2. Disconnect the spark plug wire from the spark plug.
3. Securely place the disconnected spark plug wire away from the spark plug and any metal parts. This must always be done or arcing may occur between spark plug wire and metal parts.
4. Replace or repair the part on the engine or attachment.

5. Check all parts that were repaired, or removed during repair, that they are secure and fit correctly.

NOTE: All repair parts must come from the factory. Never replace parts that are not specifically designed for the engine or attachment.

6. Replace spark plug wire.

CAUTION

Avoid injury! Always wear hearing protection while operating engine.

CAUTION

Avoid injury! Please do not start your auger until you have read the previous section of this manual. If you have read these, follow the steps below to start your auger.

Preparing Engine for Starting

GAS AND OIL

Quality

To operate the engine you must use a high quality 2-cycle oil to ensure that the engine operates correctly for the life of the engine. Use unleaded regular, unleaded premium or reformulated automotive fuels only. It may contain up to 10% ethanol, 10% gasohol, 15% MTBE, and 15% ETBE. **DO NOT use Methanol or leaded fuels.**

Mixture

Run earth auger with a ratio of 50:1. **DO NOT use marine 2-cycle oil.** See chart below.

<u>GAS</u>	<u>OIL</u>	<u>RATIO</u>
1 gallon	2.5 ounces	50:1
2 gallons	5 ounces	50:1
5 gallons	13 ounces	50:1

Mixing Fuel and Filling Fuel Tank

CAUTION

Avoid injury! Never store engine with fuel in the tank indoors. Fuel and fuel vapors are highly flammable.

CAUTION

Avoid injury! Never mix fuel and oil directly in engine fuel tank. Use only non-metal, portable fuel containers approved by the Underwriter's Laboratory (U.L.) or the American Society for Testing & Materials (ASTM).

CAUTION

Avoid injury! An adult must always handle and fill the engine with fuel.

Mixing Fuel

1. Fuel must be mixed in a container outside in a well ventilated area.
2. Fill certified fuel container 1/4 full of recommended fuel.
3. Add recommended amount of 2-cycle oil. **DO NOT use 2-cycle marine oil.**
4. Screw container cap on straight and tight.
5. Shake the container to mix fuel and oil.
6. Unscrew cap slowly to vent. Add the remainder of fuel requirements.
7. Wipe away any spilled fuel or oil and allow to evaporate before moving or transporting.

CAUTION

Avoid injury! Always handle gas in a well ventilated area, outdoors, away from flames or sparks.

IMPORTANT

This engine uses a gas/oil mixture. DO NOT run on straight gas only, engine damage will result.

Filling Fuel Tank

1. Shut-off engine and allow engine to completely cool before refilling the fuel tank.
2. Move to a well ventilated area, outdoors, away from flames and sparks.
3. Clean debris from area around the fuel cap.
4. Loosen fuel cap slowly. Place the cap on a clean, dry surface.
5. Carefully add fuel without spilling.
6. Do not fill gas tank completely full, allow space for fuel to expand.
7. Immediately replace fuel cap and tighten. Wipe off spilled fuel and allow to dry before starting engine.

CAUTION

Avoid injury! DO NOT start engine if fuel is spilled. Wipe off excess fuel and allow to dry. Remove engine from area to avoid sparks.

Assembly

To attach auger to powerhead, align hole at the top of the auger shaft with the output shaft hole. Insert bolt and secure bolt with provided nut or allen wrench depending on size of auger.

NOTE: The ends of the bolt should be flush with auger collar. Bolt head and thread end should never go beyond earth collar.

Starting and Stopping Engine

1. Move engine to a well ventilated area, outdoors, to prevent carbon monoxide poisoning.
2. Move to an area away from flames or sparks, to avoid ignition of vapors if present.
3. Remove all debris from air cleaner holes and fuel cap to ensure proper air flow.
4. Turn switch to the **ON** position.

5. Priming:

- When using the primer bulb, allow the bulb to return completely to its original position between pushes.
- Choke must be in the **OFF or RUN** position when pushing or using the primer bulb.

First Start: Starting new engine for first time or after running out of gas, prime 3 times.

Cold Start: Starting engine after it has been sitting or stored briefly with fuel in the tank, prime 1 time above 55° Fahrenheit or 2 times below 55° Fahrenheit.

Warm Start: Do not use primer or full choke if engine did not run out of gas or has not cooled completely. Flooding of engine will occur.

6. Choke:

- **Full choke** position is defined by moving the choke lever as far to the **ON or CHOKE** position as possible. **Half choke** is defined when the choke lever is between **ON or CHOKE and OFF or RUN**.

First Start & Cold Start: After priming, move choke lever to full choke.

Warm Start: No choke or half choke is needed.

CAUTION

Avoid injury! Starter rope can cause an unanticipated jerk towards engine. Please follow instructions to avoid injury.

7. Grasp starter handle and pull out slowly, until it pulls slightly harder. Without letting it retract, pull rope with a rapid full arm stroke. Let it return to its original position very slowly. Repeat this step everytime the starter rope is pulled.
8. Pull recoil until engine fires or runs.
NOTE: If engine fails to start after 5-6 pulls, push primer 1 time and pull starter rope again.
9. After engine starts running, move choke lever to **HALF CHOKE**.
10. Run engine for 30 to 45 seconds at half choke position until engine warms up.
11. Move choke lever to **OFF or RUN** position and move throttle to desired speed.
12. To stop, flip switch to **OFF** position.

CAUTION

Avoid injury! If engine fails to start after the above operations, please contact Ardisam, Inc. at 1-800-345-6007.

DO NOT attempt to start engine in the following ways:

- **DO NOT use starting fluid.**
- **DO NOT spray flammable liquids or vapors into air cleaner, carburetor or spark plug chamber.**
- **DO NOT remove spark plug and pull on starter rope. Flammable fuel can spray out & ignite from a spark from spark plug.**

CAUTION

Avoid injury! Never leave engine running while unattended. Turn off after every use.

CAUTION

Avoid injury! Never carry powerhead and auger between holes while engine is running.

Normal Operation

1. The clutch will transfer maximum power after about two hours of normal operation. During this break-in period clutch slippage may occur. The clutch should be kept free of oil and other moisture for efficient operation.
2. Dig holes without placing excessive body weight on the unit. The auger operates most efficiently with a shaving action caused by the weight of the unit itself.
3. Never run engine indoors. Exhaust fumes are deadly.

Using The Screw Type, Manual Venting Gas Cap

Your power earth auger is equipped with a screw type, manual venting gas cap.

1. Before starting the engine, turn the screw in the top of the gas cap two to three turns (counterclockwise) to its venting position. **DO NOT turn the screw to the point that it stops (4-5 turns counterclockwise).** To ensure that gas will not spill during use, check that the gas cap is screwed on tightly and the gas cap screw is in the venting position.
2. After using the power earth auger and before putting away or transporting it in a vehicle, screw the gas cap screw on (clockwise) tightly. This will prevent gas from leaking during storage. The gas cap will not leak gas during storage if the gas cap is tight and the screw at the top is tight.

**CAUTION****To prevent accidental starting:**

Avoid injury! Engine must be turned off and cool, and spark plug wire must be removed from spark plug before checking and adjusting engine or equipment.

**CAUTION**

Avoid injury! Temperature of muffler and nearby areas may exceed 150° F (65° C). Avoid these areas.

**CAUTION**

Avoid injury! Check auger often for loose nuts and bolts. Keep these items tightened.

Auger Maintenance

1. The gear case has 4 oz. of grease installed at the factory. It is recommended that once a year the gear case be split and the grease level checked. Add grease only if level of grease is below top of the gears. A high quality lithium grease is recommended, which can be purchased at most automotive and hardware stores. **DO NOT OVERFILL.**
2. Keep all screws, nuts, and bolts tight.
3. For cold weather operation, store the unit in a cool environment. Transferring the unit from a warm to a cold place can cause the build up of harmful condensation.

Engine Maintenance**CAUTION**

Avoid injury! Never store engine with fuel in the tank inside a building. Potential sparks may be present for ignition of fuel and fuel vapors.

**CAUTION**

Avoid injury! An adult must always do maintenance and repair on engine and attachments.

**CAUTION**

Avoid injury! Engine must be shut-off, cool, and spark plug wire removed before any repair or maintenance can be done.

Cooling Fins

- Cooling fins, air inlets and linkages must be free from any debris before each use.

Air Filters

- Never run engine without air cleaner properly installed. Added wear and engine failure may occur if air cleaner is not installed on engine.
- Service air cleaner every 3 months or after 20 hours of operation. **Clean and oil filter daily in extremely dusty conditions.**

Steps for Cleaning Air Filters

Never twist air filters when cleaning. Always press.

1. Wash in warm water with mild soap until dirt and debris are removed. Press filter when washing, do not twist.
2. Rinse in warm water until soap and dirt are removed.
3. Dry filter by wrapping in a clean cloth and pressing filter until it is dry.
4. Apply oil to the entire filter.
5. Remove excess oil.
6. Attach the filter and filter cover to the engine.

Spark Plug

- Check spark plug every 50 operating hours.
1. Remove dirt and debris around the spark plug before removing.
 2. Remove spark plug and replace if any of the following have occurred: pitted electrodes, burned electrodes, cracked porcelain, or deposits around the electrodes.
 3. Check spark plug for proper gap (.025" to .030").
 4. After analysis of the spark plug, install original or a new spark plug and tighten securely.

NOTE: DO NOT OVERTIGHTEN!

NOTE: CROSS REFERENCE SPARK PLUG IS CHAMPION CJ8.

Carburetor

- Never tamper with factory setting of the carburetor.

Transporting Your Earth Auger

1. Never transport engine inside an enclosed space or vehicle. Fuel or fuel vapors may ignite causing serious injury or death.
2. If fuel is present in the fuel tank, transport in an open vehicle in an upright position.
3. If an enclosed vehicle must be used, remove gas into an approved red gasoline container. DO NOT siphon by mouth.
4. Run engine to use up the fuel in the carburetor and fuel tank. Always run engine in a well ventilated area.
5. Wipe away any spilled fuel from engine and earth auger. Allow to dry.

Long Term Storage

- If your earth auger will not be used for more than one month, prepare it for long term storage.

Steps for Long Term Storage

1. Add fuel stabilizer according to manufacturer's instructions.
2. Run engine for 10-15 minutes to ensure that the stabilizer reaches the carburetor.
3. Remove the remainder of the fuel from the gas tank into an approved fuel container.

**CAUTION**

Avoid injury! To avoid injury or death, never siphon fuel by mouth.

**CAUTION**

Avoid injury! Never store earth auger with fuel in the fuel tank inside an enclosed area or building.

4. Remove auger from powerhead and apply a thin layer of grease to the output shaft (8913).
5. Store auger and powerhead (engine) in a vertical position.
6. Remove all debris from auger and powerhead (engine).

SERVICE INFORMATION

IN CASE OF A SERVICE PROBLEM, DO NOT SEND UNIT BACK TO RETAILER. CONTACT ARDISAM, INC. AT 1-800-345-6007. WE WELCOME YOUR CALL.

At Ardisam, we build quality and durability into the design of our products; but no amount of careful design by us, and careful maintenance by you, can guarantee a repair-free life for your auger. Most repairs will be minor, and easily fixed by following the suggestions in the troubleshooting guide in this section.

The guide will help you pinpoint the causes of common problems and identify remedies.

For more complicated repairs, you may want to rely on your retailer, an authorized mechanic or Ardisam, Inc. (contact your retailer for a list of authorized mechanics in your area). A parts catalog is included in this section.

We will always be glad to answer any questions you have, or help you find suitable assistance. To order parts or inquire about warranty, call or write us at the address found in the next column under the section ordering repair parts or check out our website - www.ardisam.com.

ORDERING REPAIR PARTS

Parts can be obtained from the store where your auger was purchased or direct from the factory. To order from the factory, call or write to:

Ardisam, Inc.

1690 Elm Street, Cumberland, WI 54829

Phone (715) 822-2415 Fax (715) 822-2223

1-800-345-6007

Email info@ardisam.com

www.ardisam.com

Please include the following information with your order:

1. Part numbers
2. Part description
3. Quantity
4. Model number and serial number




CAUTION

Practice safety at all times. Engine must be turned off and allowed to cool, and spark plug wire must be disconnected before attempting any maintenance or repair.

TROUBLESHOOTING

Problem	Possible cause	Remedy/Action
Engine will not start	<ol style="list-style-type: none"> 1. Power switch off 2. Spark plug wire disconnected 	<ol style="list-style-type: none"> 1. Flip switch to on position 2. Connect spark plug wire to spark plug
Engine runs rough, floods during operation	<ol style="list-style-type: none"> 1. Dirty air cleaner 2. Choke partially engaged 3. Carburetor out of adjustment 	<ol style="list-style-type: none"> 1. Clean or replace air cleaner 2. Turn off choke 3. Call factory
Engine is hard to start	<ol style="list-style-type: none"> 1. Stale fuel 2. Spark plug wire loose 3. Dirty carburetor 	<ol style="list-style-type: none"> 1. Drain old fuel and replace with fresh. Use gas stabilizer at end of season 2. Make sure spark wire is securely attached to spark plug 3. Clean carburetor, use gas stabilizer, new gas can
Engine misses or lacks power	<ol style="list-style-type: none"> 1. Clogged fuel tank 2. Clogged air cleaner 3. Improper carburetor adjustment 4. Spark plug dirty, improper gap, or wrong type 	<ol style="list-style-type: none"> 1. Remove and clean 2. Clean or replace 3. Call factory 4. Replace spark plug and adjust gap
Auger turns at idle	<ol style="list-style-type: none"> 1. Idle speed too high 2. Broken clutch spring 	<ol style="list-style-type: none"> 1. Adjust idle speed lower 2. Replace both springs
Auger turns, but has no power	<ol style="list-style-type: none"> 1. Choke on 2. Carburetor out of adjustment 3. Broken transmission 4. Worn clutch shoes 5. Worn engine lower seal 	<ol style="list-style-type: none"> 1. Turn off choke after engine is running 2. Call factory 3. Call factory 4. Replace clutch shoes and springs 5. Call factory
Auger jumps	<ol style="list-style-type: none"> 1. Blades damaged 	<ol style="list-style-type: none"> 1. Install new blades
Auger cuts slowly	<ol style="list-style-type: none"> 1. Dull blades 2. Damaged fishtail point 	<ol style="list-style-type: none"> 1. Replace blades 2. Replace fishtail point
Engine runs, then quits	<ol style="list-style-type: none"> 1. Gas cap not venting 	<ol style="list-style-type: none"> 1. Make sure gas cap screw is unscrewed 2-3 turns (counterclockwise) before starting engine
Engine revs too high	<ol style="list-style-type: none"> 1. Low fuel in tank 	<ol style="list-style-type: none"> 1. Add fuel to tank




MINIMUM ORDER \$10.00

POWERHEAD PARTS

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
1021	SWITCH, ROCKER	1	300472	COIL, IGNITION	1
4812	COVER, MUFFLER, METAL	1	300475	GASKET, MUFFLER	1
4813	MUFFLER, CATALYTIC CONVERTER	1	300476	GASKET, INTAKE	2
300401	CAP, FUEL, MANUAL VENTING	1	300477	HEAT DISK	1
300412	SPRING, CLUTCH	1	300478	WINDPIPE, INTAKE	1
300413	CLUTCH ROTOR ASSEMBLY	1	300479	GASKET, CARBURETOR	1
300429	PLATE, RECOIL	1	300480	SPACER, FUEL TANK THREADED	2
300430	RECOIL ASSEMBLY	1	300481	O-RING	1
300435	FILTER, AIR	1	300482	SHROUD, ENGINE	1
300437	FUEL TANK	1	300483	COVER, ENGINE SHROUD	1
300438	BOLT W/WASHER, M5 X 25MM	2	300484	FLYWHEEL, MAGNETO	1
300439	BOLT W/WASHER, M5 X 18MM	13	300486	CARBURETOR	1
300444	SUPPORT, FUEL TANK, LEFT	1	300487	COVER, ENGINE MOUNTING	1
300444R	SUPPORT, FUEL TANK, RIGHT	1	300488	CHOKE	1
300445	WASHER, M5	2	300489	LEVER, CHOKE	1
300449	WASHER, SPRING	2	300491	RECOIL CLUTCH	1
300450	BOLT, SHOULDER	2	300492	NUT, M6	2
300454	BASE, INTAKE	1	300493	BOLT, STUD M6 X 62MM	2
300455	PLATE, INTAKE COVER ADAPTER	1	300494	GROMMET, FUEL TANK, DOUBLE HOLE	1
300456	BOLT, M5 X 50MM	2	300497	HOSE, PRIMER LINE 4"	1
300457	COVER, AIR FILTER	1	300498	HOSE, PRIMER LINE 9"	1
300458	COVER, INTAKE	1	3004103	FILTER, FUEL (NOT SHOWN)	1
300463	GROMMET, ENGINE SHROUD	1	3004105	KIT, GROMMET & FUEL LINES (NOT SHOWN)	1
300467	PIN, LOCATING	2	BM6A	SPARK PLUG	1
300470	KIT, FUEL LINE HOSE & FILTER (NOT SHOWN)	1			
300471	BOLT, M5 X 12MM	3			

Earthquake® E43 PARTS LIST



MINIMUM ORDER \$10.00

POWERHEAD PARTS

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>	<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
1022	RING, ADAPTER (engine to handlebar plate)	1	8915	PIN, DOWEL 1/4" X 1/2", HARDENED STEEL	1
1023	BOLT, M6 X 1 X 16MM (ring to engine)	4	8919	GASKET	1
1024F	HANDLEBAR	1	8922	BALL BEARING	3
4800	THROTTLE HOUSING	1	8923	BALL BEARING	2
4802	SPRING, TRIGGER TORSION	1	8924	SNAP RING	2
4803	PIN, CLEVIS, GROOVED 188 DIA.	1	8929	BOLT-SHCS, 1/4-20 X 1-1/2"	2
4804	E-CLIP	1	8931F	BOLT-SHCS, 1/4-20 X 2"	4
4806	TRIGGER, THROTTLE	1		(gear case to ring)	
4807	SCREW-SOC HD CAP, 6-32 UNC X 1/2"	1	8939	GEAR CASE BOTTOM	1
4808	THROTTLE BARREL (NOT SHOWN)	1	8985	GEAR CASE TOP	1
4809	THROTTLE TRIGGER ASSEMBLY	1	9214	48T & 10T PINION GEAR CLUSTER, LEFT THRD .	1
	(includes 4800, 4802, 4803, 4804, 4806, 4807, 4810)		9814MM	PINION GEAR, 7 TOOTH THREADED	1
4810	NUT NYLOK NM NYLON 6-32 ZN	1	300409	SPACER-DRUM	1
4811	CABLE, THROTTLE	1	300414	CLUTCH DRUM	1
8904WC	SCREW-PHILIPS PAN HD, #10 X 1-1/4"	1	300499	TRANSMISSION COMPLETE	1
8912	GEAR 44T	1	E43CC	GAS ENGINE, 43CC	1
8913	OUTPUT SHAFT 7/8"	1	IBE43	INSTRUCTION BOOKLET	1

Earthquake[®]

Ardisam, Inc.
1690 Elm Street, Cumberland, Wisconsin 54829
Phone (715)822-2415 • Fax (715)822-2223
1-800-345-6007

Email info@ardisam.com

www.ardisam.com